



XM SATELLITE RADIO 200-FOOT EXTENSION KIT; USE WITH EXISTING SYSTEMS

EXTREME CAUTION SHOULD BE TAKEN WHEN MOUNTING THESE COMPONENTS TO THE BUILDING. AVOID POWER LINES & FOLLOW ALL LOCAL INSTALLATION CODES FOR INSTALLING THIS TYPE OF EQUIPMENT.

KIT INCLUDES:

1. IN-LINE AMPLIFIER (CP-03243)
2. 200' RF-195 TYPE CABLE (CP-03258)

Adjusting the length of any of the cables will degrade signal performance.

INSTALLATION INSTRUCTIONS:

1. Take the EXISTING system and locate the end of the cable that is connected to the splitter/distribution amplifier that is also connected to the receivers. Disconnect this cable.
2. Attach the new in-line amplifier that comes with this kit and to the existing cable. It is very important that the side that does NOT state towards receiver is attached, to this cable.
3. Connect the 200' cable to that comes with this system to the other side of the in-line amplifier. Attach to the side of the in-line amp that has the label stating;”**OUT TO RECEIVER**”. Feed the 200' cable towards the location of the receivers.
4. Attach the existing splitter/ amplifier that was with the other system to the other end of the new 200' cable.
5. Reattach each of the connector of the splitter to each receiver.

