



INTEROPERABLE SATELLITE RADIO 175-FOOT; FOUR RECEIVER SYSTEM

EXTREME CAUTION SHOULD BE TAKEN WHEN MOUNTING THESE COMPONENTS TO THE BUILDING. AVOID POWER LINES & FOLLOW ALL LOCAL INSTALLATION CODES FOR INSTALLING THIS TYPE OF EQUIPMENT.

KIT INCLUDES:

1. AMPLIFIED ANTENNA ON A BRACKET
2. J-POLE, VAPOR WRAP, 2 TIE WRAPS, & U-BOLT.
3. 175' RG-58 TYPE CABLE
4. AMPLIFIER W/ 4-WAY SPLITTER W/ 20' CABLES (W/SMB)

Parts needed; that are **not supplied**.

- Six 5/16 X 3" lag screws to mount pole to building
- Six 5/16" washers
- Hardware to properly ground the system.
- Addition straps to support cable along beams.

Adjusting the length of any of the cables will degrade signal performance.

INSTALLATION INSTRUCTIONS:

1. Take the antenna and mount it to the J-pole as shown below, with the supplied U-bolt. Attach the J-pole to the top or side of the building and secure as necessary. Make certain the amplified antenna is horizontal.
2. Attach the 175' cable to the antenna and wrap this connection with the supplied vapor wrap. Attach the cable to the J-pole to secure it with the supplied tie-wraps.
3. Feed cable through building and towards the receiver. Attach the four-way splitter to the other end of the cable.
4. Attach each SMB connector of the splitter to each receiver. Plug in the AC adapter of the splitter into the wall out-let.

